

# smartSTEER

Steering and control has never been easier

A better driving experience with **smartSTEER**

**smartSTEER** is a handheld steering device, which enables the driver to operate the vehicle's secondary functions at the touch of a button. With the option of up to 10 or 13 way functions, the **smartSTEER** can typically control:



## Functions

- Indicators & hazard lights
- Headlights
- Horn
- Windscreen wipers (front and rear)
- Windscreen washers (front and rear)
- Fog lights
- Other functions are possible, depending on the vehicle, eg Radio on/off, heated windscreen, etc



The design of the **smartSTEER** is ergonomic and robust to provide assured and safe control whilst also offering variable positioning on the steering wheel for maximum comfort. The **smartSTEER** has an automatic dimming handset and can be quickly released from the steering wheel when not in use, or when the vehicle is left unattended.

**smartSTEER** works exceptionally well in tandem with either the **smartDRIVE**, or the **smartTWIN-FLIP** for stroke sufferers, amputees, people with leg/foot injuries either temporary or permanent or 'drive from wheelchair' users.



# smartSTEER

Steering and control has never been easier

## Why use smartSTEER?



Unlike a conventional steering ball there is no separate fixed position keypad. The smartSTEER integrates control of the steering and operation of secondary

functions. This makes identifying the correct switch easy whilst the driver remains in complete control, for example when negotiating and signalling to exit a roundabout

The smartSTEER is balanced so that the operating buttons are always in the correct position, without the driver having to correct the handset when negotiating a corner or returning to the vehicle.

### SmartSteer fits all conventional and Multiplex/Canbus vehicles

- smartSTEER comes with a 5 year guarantee rather than the usual 12 months
- smartSTEER is suitable for both right and left handed drivers, making it extremely adaptable
- smartSTEER automatically cancels the indicators, the driver doesn't have to do it manually (optional)



Other products in the smartDRIVING CONTROLS range include:

### smartDRIVE smartDRIVE+

Push Pull hand controls for hand operation of the brake and accelerator pedal. Optional integral indicator switch can be built into the handle.



### smartRELEASE

Easy release mechanism for your handbrake. Requires less strength and dexterity.



### smartGUARD

Quick release pedal guard to prevent accidental use of the foot pedals.



### smartTWIN-FLIP

Flip up left foot accelerator to switch from left to right foot accelerator operation.



### smartBALL smartBALL+

Standard or Quick Release steering balls for safe one handed steering.



### smartHINGE

Hinged accelerator pedal to flip up the accelerator pedal when not required.



Motability accredited.  
NEMEDA approved.

Autochair have over 30 years experience in the design and manufacture of vehicle adaptations to assist people with disabilities and reduced mobility - call us today to find your new freedom with Autochair:  
**0800 214 045**

Autochair reserve the right to change product specifications or appearance without prior notice through product development and improvement. We aim to ensure our customers are aware of this at the time of ordering.